







Doc. nr. 9124710	Rev. 0	Registration form. Re-placement Fuse holder	
----------------------------	------------------	---	---

	<p>Step 1.</p> <p>Turn unit off.</p> <p>Disconnect power plug.</p>
	<p>Step 2.</p> <p>Remove the socket head screws that secure the panel to the frame.</p> <p>Turn panel towards yourself.</p> <p>Now the electrical connections are visible</p>
	<p>Step 3.</p> <p>Check Fuse Holders;</p> <ul style="list-style-type: none"> - Open fuse holder, - Remove Fuse, - Control fuse holder on burning spots, - If burned, replace <u>fuse holder.</u> - Replace Fuse, - Close fuse holder.
	<p>Step 4.</p> <p>Re-position fuse holders</p> 
	<p>Step 5.</p> <p>Put power plug into wall socket</p> <p>Turn unit on.</p>