Doc. nr.	Rev.	Registration form.	
9124301	A	Adjusting Danfoss ERC211 & ERC213 thermostat	fri-jado

Changing temperature setpoint

Example screens

1. Press SET briefly to access setpoint mode	85
2. Change value with ∧ or ∨	80
3. Press SET to confirm	80
When no key is pressed after last confirmation, the system goes back to normal operation after 10 seconds	

Programming menu

Example screens

1. Press SET for 3 seconds to access the menu	in
2. Scroll through parameter groups with ∧ and ∨	in, cF9, r--, A--, d--, c--, o--, P--, u--
3. Select parameter group with SET	o01
4. Scroll through parameter names with ∧ and ∨	o01, o02, o03, o05, o06, o07, o15, o23, o61, o67, o91
5. Press SET to read out the value	5
6. Change value with ∧ and ∨	0
7. Press SET to confirm	0
8. Press ∨ to select the next parameter and follow instruction 3 to 7	
Use < to go back in the parameter groups and once more to leave the programming menu	