INSTRUCTIONS FOR FOR EXCHANGING DANFOSS EKC TO ERC THERMOSTAT

The wiring connection numbers 1-4-2-5-13-14 on the Danfoss EKC thermostat are different than the wiring connections 3L-2-4N-1-9-10 on the ERC thermostat. keep this in mind when you change the EKC for the ERC thermostat. See also the drawing below.