Mounting Instruction

Nock-out in fan plate for TDR5m

Break out for use in TDR5m

TDR5m

DO NOT break out when used in TDR5p!!

TDR5p

Contents service kit 9290458s:

9290458	1x	Fan plate
9124249		This instruction

Note that when 9290475s is ordered, (=9290458s with nock-out allready removed), the 9290458s will be sent.

- NOTICE -

This manual is prepared for the use of trained Service Technicians and should not be used by those not properly qualified. If you have attended a training for this product, you may be qualified to perform all the procedures in this manual.

This manual is not intended to be all encompassing. If you have not attended a training for this product, you should read, in its entirety, the repair procedure you wish to perform to determine if you have the necessary tools, instruments and skills required to perform the procedure. Procedures for which you do not have the necessary tools, instruments and skills should be performed by a trained technician.

Reproduction or other use of this Manual, without the express written consent of Fri-Jado, is prohibited.