



FRI-JADO UNDERFRAME CD

Underframe 9268002 for CD 3

Underframe 9268102 for CD 4

Underframe 9268202 for CD 5

We recommend to use an electric screwdriver and its appropriate accessories.



